



UC-100 USB CASH DRAWER TRIGGER

OPEN YOUR CASH DRAWER DIRECTLY FROM YOUR PC OR POS SYSTEM

The Safescan UC-100 connects your Safescan cash drawer directly to your PC or POS system, allowing you to open your cash drawer with your preferred system. Simply connect the RJ-12 connector of your cash drawer to the UC-100 and connect the UC-100 to the USB port of your PC or POS system, and you are ready to go.

- RJ-12 to USB converter
- Connect your cash drawer directly to your PC or POS system
- Open your cash drawer directly from your PC or POS system
- Plug & Play connectivity
- USB powered, no external power is required
- Suitable for all Safescan cash drawers



Converts RJ-12 to USB



Connect your cash drawer directly to your PC or POS system



Fully compatible with all Safescan cash drawers

TECHNICAL SPECIFICATIONS

- Interface:	USB (computer), RJ-12 (cash drawer)
- Power requirement:	USB powered (5V, max 200mA)
- Cash drawer power specification:	12V or 24V
- Repeat rate:	max. 5 seconds
- Dimensions:	6.8 x 4.4 x 2.5 cm
- Weight:	80 gr

PACKAGE CONTENTS

- Safescan UC-100
- Quick installation guide



COMPATIBLE WITH:



Suitable for all Safescan cash drawer